



## First Evangelical Church of San Gabriel Valley

聖迦米羅省基督教會

3658 N. Walnut Grove Ave. • Rosemead, CA 91770

Tel: (626) 571-5537 • Fax: (626) 571-1040 • E-mail: office@fecsgv.org • Website: www.fecsgv.org

### Guidelines for Operating Fire Alarm System at Education Building

The fire alarm system consists of two boxes:

- The smaller one comprises an operating lever
- The bigger one is the control panel

#### Operating Lever

1. Pull lever in case of fire
2. After the fire, DO NOT force back the lever as it will break the switch inside, which is costly to repair
3. Instead, open the box and push up the switch

#### Control Panel

1. A key to the panel is hidden on top of the panel box
2. The panel will show the source of the fire alarm (level 1 or level 2 at the Education Building)
3. To reset the system, press the “reset button”

### 教育樓火警系統操作指引

火警系統包括兩個箱子：

- 較小的一個含操作杆
- 較大的一個含控制板

#### 操作杆

1. 火警發生時，拉下操作杆
2. 火警後，千萬不要用力把操作杆推回原位，因這樣會把裏面的制拉斷，維修頗貴
3. 打開箱子，把裏面的制向上推

#### 控制板

1. 箱子上面藏有鑰匙
2. 從控制板可以看到火警從一樓或二樓發出
3. 按 “reset”制使火警系統復位